

---

## TRANSPORT AND STORAGE OF PARKLEX FACADE PANELS

---

### TRANSPORT AND HANDLING OF PARKLEX PANELS

The panels must be correctly strapped down for transport, keeping in mind that they slide over each other easily and may become damaged. They must always be transported horizontally.

The panels must never be transported loose or with broken straps. For short trips in workshops or on the construction site, fasten the panels using straps, protecting the edges in contact with the straps with cardboard corner protectors. Avoid foreign bodies between panels and contact with objects with sharp edges or corners that might damage the panels. When moving panels on the same pallet, lift them so that they do not drag on top of one another.

### STORING PARKLEX PANELS

Parklex panels must be stored according to the following instructions:

a) Horizontal storage: Panels must be stored in a horizontal position, never in a vertical or slanted position, preventing them from resting on objects or residues that keep them from being completely horizontal.

b) Optimal storage conditions: To prevent deformations, store in a clean, dry place, protected from rain and sun. Recommended storage conditions are a Temperature of 73°F (±36°F) and a Relative Humidity of 50% (±5%).  
Climatic differences on the two panel surfaces are to be avoided.

c) Removing the protective film: The panels for exteriors are covered with a protective film on their exposed side, which must be removed immediately after installing the panel, as prolonged exposure to the sun will cause the adhesive on the film to soil the panel.